



**LANDING BANISTER**

# BOSTON

**INSTRUCTION / MONTAGEANLEITUNG  
INSTRUKTION / INSTRUCCIÓN / INSTRUKCJA**

**SOGEM®**

PART OF DOLLE GROUP

**Start kit / Anfangspaket / Startpakket  
Kit de départ / Startpakke / Pakiet startowy**

<p>8</p> <p>958</p> <p>Ø25</p>	<p>26</p> <p>x 4 K2-1077125 RAL 7016 K2-1077126 RAL 9005 K2-1077127 Pearl grey K2-1077128 RAL 9016</p>	<p>27</p> <p>x 2 K1-1077150 RAL 7016 K1-1077151 RAL 9005 K1-1077152 Pearl grey K1-1077153 RAL 9016</p>	<p>28</p> <p>Ø12</p> <p>x 1 K3-08041</p>	<p>29 x 16</p> <p>K1-04041</p>	<p>30 x 8</p> <p>K1-40296 Black / Schwarz / Zwart / Noir / Sort / Czarny K1-40396 White / Weiss / Wit / Blanc / Hvid / Biały</p>	
	<p>32</p> <p>Ø40</p> <p>x 1 Beech / Buche / Beuk / Hêtre / Bøg / Buk Oak / Eiche / Eik / Chêne / Eg / Dąb</p>	<p>1000</p>				
	<p>33</p> <p>Ø6</p> <p>x 4 K1-14070</p>	<p>1000</p>				
	<p>34</p> <p>x 1 K2-1077155 RAL 7016 K2-1077156 RAL 9005 K2-1077157 Pearl grey K2-1077158 RAL 9016</p>	<p>36</p> <p>x 2 K2-1077170 RAL 7016 K2-1077171 RAL 9005 K2-1077172 Pearl grey K2-1077173 RAL 9016</p>	<p>37</p> <p>x 2 K1-1077165 RAL 7016 K1-1077166 RAL 9005 K1-1077167 Pearl grey K1-1077168 RAL 9016</p>			
	<p>38</p> <p>x 1 K1-01620</p>	<p>47</p> <p>x 14 K3-08003 Ø8 x 50</p>	<p>48</p> <p>x 12 K3-06110 Ø5 x 60 TX25</p>	<p>50</p> <p>x 1 K1-23345</p>	<p>51</p> <p>x 10 K3-06022 Ø5 x 35 TX25</p>	<p>x 4 K2-1077135 RAL 7016 K2-1077136 RAL 9005 K2-1077137 Pearl grey K2-1077138 RAL 9016</p>
<p>52</p> <p>x 4 K3-02101 M5 x 25</p>	<p>53</p> <p>x 16 K1-04040 M6 x 16</p>	<p>56</p> <p>x 1 K3-06290 Ø4,5 x 40 TX20</p>	<p>57</p> <p>x 1 K3-06120 Ø5 x 60</p>	<p>58</p> <p>x 1 K3-90005</p>	<p>Wood glue Holzkleber Houtlijm Colle à bois Trælim Klej do drewna</p>	

**Extension kit / Ergänzungspaket / Uitbreidingsset  
Kit de suite / Forlængerpakke / Pakiet uzupełniający**

<p>8</p> <p>958</p> <p>Ø25</p>	<p>26</p> <p>x 3</p> <p>K2-1077125 RAL 7016 K2-1077126 RAL 9005 K2-1077127 Pearl grey K2-1077128 RAL 9016</p>	<p>28</p> <p>x 1</p> <p>K3-08041</p> <p>Ø12</p>	<p>29</p> <p>x 12</p> <p>K1-04041</p>	<p>31</p> <p>x 4</p> <p>K1-14939</p>
	<p>32</p> <p>Ø40</p> <p>x 1</p> <p>Beech / Buche / Hêtre / Bøg / Buk Oak / Eiche / Chêne / Eg / Dąb</p> <p>1000</p>			
	<p>33</p> <p>Ø6</p> <p>x 4</p> <p>K1-14070</p> <p>1000</p>			
	<p>47</p> <p>x 9</p> <p>K3-08003 Ø8 x 50</p>	<p>48</p> <p>x 9</p> <p>K3-06110 Ø5 x 60 TX25</p>	<p>49</p> <p>x 1</p> <p>K3-90001</p> <p>Strong glue Superkleber Seconde lijm Colle forte Superlim Mocny klej</p>	<p>51</p> <p>x 6</p> <p>K3-06022 Ø5 x 35 TX25</p>
<p>52</p> <p>x 3</p> <p>K3-02101 M5 x 25</p>	<p>53</p> <p>x 12</p> <p>K1-04040 M6 x 16</p>			

**OPTION / MÖGLICHKEIT / OPTIE  
OPTION / MULIGHED / OPCJA**

<p>28</p> <p>x 2</p> <p>K3-08041</p>	<p>35</p> <p>x 1</p> <p>K1-1077085 RAL 7016 K1-1077086 RAL 9005 K1-1077087 Pearl grey K1-1077088 RAL 9016</p>	<p>38</p> <p>x 4</p> <p>K1-14941</p>	<p>49</p> <p>x 1</p> <p>K3-90001</p> <p>Strong glue Superkleber Seconde lijm Colle forte Superlim Mocny klej</p>
--------------------------------------	---------------------------------------------------------------------------------------------------------------------------	--------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------

**Corner kit / Eckenpaket / Hoekset  
Kit d'angle / Hjørnepakke / Zestaw złączek kątowych**

TX22  
TX25

Ø 3mm  
Ø 4mm  
Ø 8mm  
Ø 12mm

**Tools not included!**  
Werkzeuge nicht enthalten!  
Gereedschap niet inbegrepen!  
Outils non inclus!  
Værktøj ikke inkluderet!  
Narzędzia nie znajdują się w zestawie!

2,5 mm  
6 mm























