



1986530 Colorado

- S. Montera taklampan enligt bilden nedan. 3xMR16 max 20W.
- D. Montieren Sie die Lampe laut Skizze. 3xMR16 max 20W.
- F. Montez la lampe conformément au croquis. 3xMR16 max 20W.
- N. Monter sammen delene som anvist i tegningen. 3xMR16 max 20W.
- SF. Asenna osat piirustuksen mukaisesti. 3xMR16 max 20W.

