

## ASSEMBLY INSTRUCTIONS

Read this instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture part on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.


### CAUTIONS :

1. Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
2. To prevent thread damage. Ensure that nuts or nut bolts are not over-tighten.
3. Hardware are to be kept out of reach from children.

PART LIST		
ITEM	DESCRIPTION	QTY
A	CUSHION SEAT	1 PC
B	LEG ( L & R )	2 PCS
C	APRON	2 PCS


HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC SCREW M6 x 50MM 	4 PCS
2	JCBC SCREW M6 x 60MM 	4 PCS
3	SPRING WASHER 1/4" 	8 PCS
4	M4 ALLEN KEY (BALL SHAPE) LONG 	1 PC
5	WOOD DOWEL DIA 8 x 35MM 	8 PCS
6	ADJUSTABLE SCREW C89 	4 PCS

### STEP 1



REMARK: HOLE MARKING AT RIGHT FRONT LEG


### STEP 2



**STEP 3**

**Maximum Load Capacity**

**120 kg**



**COMPLETED CHAIR ASSEMBLY**