
## Items number: 7701160





## Items number: 7701160



House Nordic delivers the beautiful, crocheted parasol including a cover.

Using the cover increases the parasol's lifespan and provides extra protection against all kinds of weather conditions when it is not in use, such as dust, wind, and rain. For parasols with a combination of wood and crocheted parasol fabric, care for the fabric by cleaning with pH-neutral soap water.

If it gets soaked, it should be dried immediately to prevent the material from deteriorating prematurely or becoming moldy.

Storage: It is recommended to store wooden parasols in a dry, frost-free, and ventilated area outside the summer season.

Over time, a natural patina will appear on the wood due to weathering, and small cracks and splits may occur.

This does not affect the wood's strength, provided regular oiling is ensured to prevent the wood from drying out.

Maintenance products: Ask for maintenance products at your local hardware store.

