

lighting system.

any circumstances. No matter how extensive the setup is, won't let you down.

In renovation or building new, in ordinary or more demanding project, the nonexistence of wall switch cables saves time and money and offers an efficient way to carry out the most functional lighting control.

Lighting Control System offer an easy and safe way to improve your Millions of unique device addresses ensures troublefree operation in

- Om inget annat anges får all JOHDOTON-apparatur installeras och användas endast i ett torrt utrymme och i torra förhållanden
- JOHDOTON-apparatur får inte användas i explosionsfarliga utrymmen!
- Dimmer - kontroll: se sidan 4, avsnitt 6

Funktionsväljare i läge 2:

- Ett tryck: "Scenstatus" 1, PA - Dubbeltryck: "Scenstatus" 2, PA - Trippeltryck: "Scenstatus" 3, PA - Ett långt tryck: AV

- Ett tryck (PA) => AVM-10s indikationsljus blinkar en gång grönt och visar därefter kontinuerligt grönt.
- Dubbeltryck (AV) => AVM-10s indikationsljus blinkar två gånger rött och

slocknar efter det.

Ljusstyrkejusteringen ändrar riktning vid varje ny start vilket gör det lättare att hitta den önskade ljusstyrkan.

NOTERA! Mottagare av M-serie slutar självjusteringen när den lägsta eller

högsta punkten i ljusstyrkan har nåtts. För att fortsätta med justeringen, starta enheten på nytt. LC-seriens mottagare slutar aldrig självjusteringen automatiskt.

To modificate a saved state just turn the state to be modified on, make desired

changes and save it again as advised on the page 22, section 8.

the battery compartment cover with battery back in place

6. When ready remove the battery compartment cover, move the selector

switch from position 3 to position 2 and put the battery compartment cover

with battery back in place

Importer and Wholeseller:

Rele & Ratas Ltd www.johdoton.fi

9 10
11 12
21 22 23
24