

Tekniset tiedot ovat paketin päällä. Teknisk data är tryckt på paketet. Technical data is printed on package.

HUOM! Asennuksen saa suorittaa vain sähköalan ammattilainen voimassa olevien säännösten mukaisesti.

Ennen asennusta varmista kotisivuiltamme www.lapetek.com että käytössäsi on uusin asennusohje. Pistorasian saa asentaa vain kahta kovaa seinäpintaa (esim. seinä ja kaappi) vasten, katso kuva 1. Pistorasian avoimien taustasivujen tulee olla asennuksen jälkeen täysin ummessa. Syöttökaapelin saa tuoda vain pistorasian takapuolelta, suoraan seinästä tai kaapista.


OBS! Installationen får se endast av en auktoriserad installatör enligt gällande regler.

Förrän du monterar produkten, kolla att du har den nyaste bruksanvisningen från www.lapetek.com. Stickdosan bör installeras mot två hårda ytor (t.ex. vägg och skåp), bild 1. Stickdosans öppna bakre sidor skall vara helt täckta efter monteringen. Kopplingskabeln kan föras in bara från baksidan av stickdosan.


NOTE! Installation must be done by an authorized person.

Before installation check the latest assembling instruction from www.lapetek.com. The socket must be installed against two closed surfaces (f. ex. wall and cabinet), picture 1. The open backparts of socket must after installation be closed. Power feed connection must be done from behind of the sockets.


LAPETEK




DELTA




MINI-1



MINI-2



MINI-3



MIRO-2

