













KRIS 40












TENE




KRIS 40






KRIS 40




EX22

EX21

EX20











Ø 4 mm






5x70 mm

KRIS 40








KRIS 40



KRIS 40






ø 50 mm

If using Tene heater set
ø 325 mm

200 mm

ø 50 mm





KRIS 40



